How to size SEG prints to frames.



Step 1.

• Measure outside dimensions of frame Example frame: 11"w x 15" t



Step 3. Inserting the finished graphic in frame.

• Start with inserting 4 corners.



Step 2.

Example frame: 11"w x 15" t

- The print needs 3/8" bleed all around.
- Finished print size needs to be: 11 3/4" x 15 3/4".
- Sew silicon strip (Keder) to 4 outside edges of the back of print.



Step 4. After 4 corners are in.

• Finish by Inserting top, bottom and then the sides.