




## STEP 1



**Lay** out the frame pieces with the thin flat sides down, forming the shape of your finished frame. For guidance, your frame may be color coded, match the color dots on each coordinating end.



**Lay** out your corners and other hardware separately. Pair a smooth corner bracket with a corner bracket with set screws. Make sure the set screws inserts are facing out.

## STEP 2




**Large** frames may have stabilizer supports and 180 connectors. Stabilizers will provide support through frames with seams and 180 connectors will connect the seam cuts. It is suggested to start with the optional hardware assembly before assembling the corners.

## Corner Hardware



**Insert** one pair of corner brackets into the open channel on two adjoining corner ends of the aluminum extrusion, sliding in to create a corner or 90 angle. Slightly tighten the screws and repeat for the remaining corners..

## Optional Hardware



180 Connector

**Match** pairs of 180 connectors with set screws out. Insert these plates into the open channels to adjoin the straight edges. It is suggested to work in parallels or opposite sides before fully pushing lengths together. Stabilizer hardware may need to be inserted before full assembly.



Stabilizer

Match your stabilizer lengths with coordinatig expansion hardware. Slide the expansion hardware into the stabilizer end and slightly tighten the set screw to hold into place. Now slide that end into the inside frame channel, once in place next to the seam, tighten the screw until secure.



## STEP 3 - Wall Mounting




**Prepare** the install location to ensure your frame will be accurately placed. Begin by marking the intended install location for the top wall mount brackets. Each cut length will receive 2 wall mount brackets, depending on size. Ensure the top of each bracket is level and the screw is through the top at least 1/4 inch. Secure the bracket to the wall and test the frame by hanging it on top of the brackets. If necessary adjust the screw to level the frame.



**Once** your frame is level and the top mounting brackets have been installed, add the bottom wall mount brackets to finish securing the frame. The sides of your frame may not have wall mount brackets but additional can be installed for additional security, usually only on very large frames. Once complete your frame should be secure and snug to the wall.

## STEP 3 - Ceiling Mounting



Ceiling mounts will be installed on the top SEG Section. Slide the keeper hardware into the inside/bottom channel, you may need to turn it sideways to

insert. Then place the hanging hardware around the backside of the frame so you do not interfere with the SEG channel on the front. Tighten both the top eyelet and bottom set screw to secure. If needed, remove the top length to slide the keeper hardware in the bottom channel.

## STEP 4



**To Install** the Silicone Edge Graphic Print, grab one corner. Pinch the corner so it slides into the SEG channel on the frame. Continue with the opposite corner, and next two. Once the corners are installed, place your hands on one center side and slide your hands over the silicone edge to press the edge of the silicone into the SEG channel towards the corners, continue for the remaining sides and your frame will be complete.